
Parts Manual for

SMAPPER

MODEL 2100HHB HAND HELD BLOWER



IT IS THE POLICY OF SNAPPER POWER EQUIPMENT TO IMPROVE ITS PRODUCTS WHENEVER IT IS POSSIBLE AND PRACTICAL TO DO SO. WE RESERVE THE RIGHT TO MAKE CHANGES OR ADD IMPROVEMENTS AT ANY TIME WITHOUT INCURRING ANY OBLIGATION TO MAKE SUCH CHANGES ON PRODUCTS MANUFACTURED PREVIOUSLY.


SNAPPER POWER EQUIPMENT

McDonough,GA • 30253



(Prod.#1-5962)

MODEL 2100HHB HOUSING COMPONENTS



MODEL 2100HHB HOUSING COMPONENTS


ITEM	PART NO.	DESCRIPTION
1	4-4521	HOUSING, Blower, Upper
2	4-4538	DECAL, Snapper (3)
3	4-4537	NOZZLE, Tapered
4	4-4523	COVER, Spark Plug
5	4-4524	GROMMET, Handle Mounting (2)
6	4-4525	HANDLE, Right Side
7	4-4526	HANDLE, Left Side
8	4-4527	TRIGGER, Throttle
9	4-4528	CABLE, Throttle
10	4-4529	SCREW, M5x20mm Pan Head (9)
11	4-4530	FAN-WHEEL
.12	4-4517	SCREW, M5x12mm Pan Head (3)
13	4-4532	HOUSING, Blower, Lower
14	4-4533	COVER, Lower
15	4-4534	SLEEVE, Tube
16	4-4535	TUBE
17	4-4536	NOZZLE, Flare
18	4-4565	WASHER, M3
19	4-4551	SCREW, Adjust
20	4-4552	NUT, Hex, M6 x1.0 (2)
21	4-4503	SPRING
22	4-4564	SCREW, M3
23	4-4579	COVER, Muffler

MODEL 2100HHB ENGINE COMPONENTS 69 ASSEMBLY -12 67['] 13-0-21-

MODEL 2100HHB ENGINE COMPONENTS

ITEM	PART NO.	DESCRIPTION
1	5-1737	RECOIL STARTER ASS'Y W/LABEL(Includes items 2&3)
2	4-4500	LABEL, Starting instruction
3	4-4502	RECOIL STARTER ASS'Y(Includes items 4thru10)
4 5	4-4561	ROPE GUIDE
6	4-4377 4-4115	ROPE, Starter
7	4-4376	KNOB, Starter SPRING, Recoil
8	4-4375	REEL
9	4-4374	WASHER
10	4-4373	SCREW
11 12	4-4328 4-4359	SCREW & WASHER(2)
13	4-4560	NUT, Conical (2) ROTOR
14	4-4031	CAP, Plug
15	4-4558	PAWL, Starter
16	4-4559	SPRING, Pawl
17 18	4-4504 4-4306	COIL,Ignition(Includes items 61 & 63)
19	4-4557	SCREW (2) GROMMET
20	4-4310	CASE, Starter
21	4-4013	SEAL, Oil (2)
22	4-4309	BEARING, Ball (2)
23 24	4-4553 4-4531	CRANKSHAFT AŚS'Y.
25	4-4405	SEAL, Engine Plate, Front PISTON
26	4-4404	RING, Piston (2)
27	4-4406	PIN, Piston
28	4-4319	CLIP, Piston Pin (2)
29 30	4-4317 4-4403	GASKET, Cylinder´ CYLINDER
31	4-4316	BOLT, Flange (2)
32	4-4327	GASKET, Carburetor Mounting (2)
33	4-4506	SHIELD, Carburetor
34 35	4-4507	SPARK PLUG (Champion CJ6)
36	4-4507	STUD, Muffler (2) SHIELD, Muffler
37	4-4510	MUFFLER
38	4-4509	NUT, Muffler Stud (2)
39 40	4-4511	SPARK ARRESTOR
41	4-4512 4-4307	CASE, Drive PIN, Dowel (2)
42	4-4308	SCREW, M5x25mm (3)
43	4-4513	FUEL TANK ASS'Y. (Includes Items 44 thru 54)
44	4-4514	LINE, Fuel
45 46	4-4515 4-4575	GROMMET, Fuel Line
47	4-4569	CLIP, Fuel Line FILTER ASS'Y, Fuel (Includes items 48, 49, 64, 65, 66, 68)
48	4-4570	CLIP
49	4-4571	SLEEVE, Gov
50 51	4-4563	CAP ASS'Y, (Includes Items 51 thru 54)
52	4-4562 4-4135	CAP, Fuel GASKET
53	4-4134	HOLDER
54	4-4133	VALVE, Breather
55 56	4-4516	MOUNT, Fan-Wheel
57	4-4517 4-4518	SCREW, M5x12mm PHCR (3) MOUNTING PLATE, Engine
58	4-4519	DAMPER,Eng.Mtg.Plate(4)
59	4-4382	PAD, Fuel Tank(4)
60 61	4-4520	SEAL, Eng. Mtg. Plate (3)
62	4-4556 4-4555	BRACKET SWITCH, Stop
63	4-4554	SCREW
64	4-4572	FELT (2)
65 66	4-4573 4-4574	RING
67	4-4574 4-4576	SCREEN SCREW
68	4-4577	BODY, Fuel Filter
69	4-4501	ENGINE. COMPLETE(Includes items 2 thru 42 & 61, 62, 63)

MODEL 2100HHB - CARBURETOR & AIR FILTER



MODEL 2100HHB - CARBURETOR & AIR FILTER

	ITE	M	PA	ART NO.		DESCRIPTION
		1		4-4547		CARBURETOR ASS'Y. (Includes Items 2 thru 32) Carb. No.
		2		4-6127		SCREW, Cover (5)
-1-		3		4-4588		COVER, Diaphragm
*	•	4		4-6103	-b	DIAPHRAGM, Metering
*	• =	5		4-4596		GASKET, Diaphragm
*		6		4-6120		PLUG, Welch
*	_	7		4-4585		PLUG, Welch
***	•	8		4-4582		RING, Screen Retainer SCREEN, Check Valve
*	•	9		4-4581		LEVER, Metering
***	•	10 11		4-6105 4-6107		PIN, Lever
1		12		4-6106		SCREW, Lever Pin
*		13		4-4587		SPRING, Lever
*	-	14		4-6110		VALVE, Inlet Needle
£		15		4-6118		SPRING, High Speed Needle
*		16		4-4591		NEEDLE, High Speed
*		17		4-6100		SPRING, Idle Needle
*		18		4-6101		NEEDLE, Idle
•		19		4-6114		SPRING, Throttle Return
		20		4-4592		SHAFT, Throttle
		21		4-4594		CLIP
		22		4-4593		SWIVEL
		23		4-6126		CLIP, Throttle Shaft
		24		4-4595		VALVE, Throttle
		25		4-2326		SCREW, Throttle
*	•	26		4-6095		SCREEN, Inlet
*	•	27		4-4586		DIAPHRAGM, Fuel Pump
*	• =	28		4-6098		GASKET, Fuel Pump
		29		4-4584		COVER, Fuel Pump
		30		4-6097		SCREW, Pump Cover
		31		4-4590 4-4589		SPRING, Idle Screw
		32 33		4-4541		SCREW, Idle Adjusting COVER, Air Cleaner
		34		4-4542		FILTER, Air Cleaner
		35		4-4539		SCREW, Carburetor Mounting (2)
		36		4-4543		PLATE
		37		4-4328		SCREW & WASHER
		38		4-4544		LEVER, Choke
		39		4-4545		BASE
		40		4-4546		SLEEVE, Choke Base (2)
		41		4-4505		GASKET, Carburetor
		42		4-4549		SCREW, Insulator Mounting
		43		4-4550		INSULATOR, Carburetor
		44		4-4548		CLIP
		45		4-4578		GASKET, Choke Base Mounting
		46		4-4597		COVER, Choke Lever

```
4-4566
4-4567
4-4568
4-4580


★ REPAIR KIT, Carburetor, Major

■ REPAIR KIT, Carburetor, Minor

■ GASKET, Carburetor/KIT, Diaphragm

□ Pump Cover KIT
```

MODEL 2100HHB ACCESSORIES



SNAPPER POWER EQUIPMENTMcDonough,GA•30253

